Management software

ThinkSystem DE Series arrays management console

Management software overview

All ThinkSystem DE Series storage arrays support the following ThinkSystem SAN OS software:

- ThinkSystem System Manager
 - A single storage system management. System Manager supports GUI only.
 - It is preinstalled on the controllers
- ThinkSystem SAN Manager
 - A host-installed GUI-based application for centralized management of multiple DE Series storage systems
 - It supports Windows or Linux host environments
- ThinkSystem Storage Manager
 - A host-installed GUI-based application, required to support the Secure CLI interface, multipath drivers, and multi-system firmware updates
 - It supports Windows or Linux host environments



Software updates in May 2020

The following software updates are included in DE Series storage arrays firmware version 11.60.2, released in May 2020:

- ThinkSystem System Manager
 - Users can now download the secure management CLI (SMcli) through System Manager
 - Synchronous and asynchronous mirroring settings have been removed from the System Manager → Storage page
- ThinkSystem SAN Manager
 - Users can now set up synchronous or asynchronous mirroring with SAN Manager (requires additional license keys)
- ThinkSystem Storage Manager
 - It is no longer bundled together with SMcli, and users will need to download SMcli with System Manager
 - In-band CLI is no longer supported

Click <u>HERE</u> to see a comparison of the DE Series 11.50.x and 11.60.2 management software. Go to the Management software section for more information.





Version 11.50.x

Storage Manager

SMcli

DSM

Host utilities

SAN Manager

Update Center

System Manager

Mirroring setup

Version 11.60.2

SMcli

DSM

Storage Manager

Host utilities

SAN Manager

Add mirroring setup

System Manager

Remove mirroring setup

Add SMcli download option

rage arrays firmware version

(SMcli) through System Manager e been removed from the System

mirroring with SAN Manager

will need to download SMcli with

DSM:


Device Specific Module

Host utilities of 11.6.2:

Storage Manager Agent Package (SMAgent)

Storage Manager Utilities Package (SMUtil)

Storage Manager Runtime Package (SMruntime)




Lenovo

Note: In-band management is supported by the 11.50.3 CLI interface for controllers running 11.50 or later versions of SAN OS. 11.60.2 or later versions do not support in-band management.

ThinkSystem System Manager

ThinkSystem System Manager (TSM) is the management console for a single DE storage system. TSM supports the web GUI. Users can monitor, configure, and perform troubleshooting actions on the storage through TSM.





Access to SAN OS

The DE Series Storage Array's operating system is SAN OS. SAN OS supports both GUI and CLI mode:

- GUI mode (ThinkSystem System Manager)
 - Open a web browser and enter the System Manager IP address to log in to System Manager
 - o It requires an Ethernet management port connection between the host and the storage array
- CLI mode (SMcli)
 - o 11.50.3 or earlier versions:
 - Storage Manager must be installed to support the secure CLI interface
 - In-band CLI from 11.50.3 can be used to manage 11.50 and 11.60 controllers
 - In-band CLI cannot manage controllers running NVMe-oF protocols
 - o 11.60.2 or later versions:
 - The out-of-band CLI interface is installed through the System Manager's System page → Add-on section
 - Runs in secure mode only
 - Requires an Ethernet management port connection




Home

Click the buttons on the left to see more information about the TSM functions.

Storage

Hardware

Settings





Home

Storage


Hardware

Settings

Support



The Home page shows live storage array performance monitoring information. If an error occurs on the storage array, an error or warning message will be displayed at the top of the Home page.







Home

Storage


Hardware

Settings

Support



If an error occurs on the storage array, users should see a warning message at the top of the Home page.









Home

Storage


Hardware

Settings

Support



The storage capacity and storage hierarchy information is displayed at the bottom of the Home page.







Home

Storage

Hardware

Settings

Support



Users can go to the Storage page to perform configuration actions on the storage. This includes pools configuration, creating and editing pools, and setting volumes and hosts. For 11.50.x users, use this page to set up synchronous or asynchronous mirroring. For 11.60.2 or later versions, use ThinkSystem Storage Manager to set up mirroring. This requires an additional license key.





Home

Users can go to the Hardware page to monitor the storage hardware status of each component – for example, drives, fans, and power supplies.


Storage

Hardware

Settings

Support








Click to enlarge the image.







Home

Storage


Hardware

Settings

Support



The System Manager page includes various storage array system setting functions.







Home

Storage


Hardware

Settings

Support



Users can configure System Manager to send storage array alerts through email, SNMP traps, and syslog messages.









Home

Storage

Hardware

Settings

Support



On the SYSTEM page, users can perform various storage system settings, such as saving the storage array configuration and enabling the premium feature key.









Home

Storage

Hardware

Settings

Support



For 11.6.2 or later versions, on the SYSTEM page → Add-ons section, users can click Command Line Interface to download and install the SAN OS command line interface (SMcli). An smcli.zip file will be downloaded to users' local system. Click HERE to see the SMcli installation tips.









Home

Storage

Hardware

Settings

Support




For 11.6.2 or later versions, on the SYSTEM page → Add-ons section, users can click Command Line Interface to download and install the SAN OS command line interface (SMcli). An smcli.zip file will be downloaded to users' local system. Click HERE to see the SMcli installation tips.












Users can use System Manager to create Certificate Signing Requests (CSRs), import certificates, and manage existing certificates.







Home

Storage


Hardware

Settings

Support



On the Support page, users can go to the SUPPORT CENTER page to collect service data, or to the EVENT LOG page to see and collect event logs for problem determination and escalation.







Home

Storage


Hardware

Settings

Support



On the SUPPORT CENTER page, users can click the Support Resource tab for a list of Lenovo website with support resources such as documentation and support telephone lists.









Home

Storage


Hardware

Settings

Support



Users can click the Diagnostics tab to collect Support Data, Drive Data, and I/O Path Statistics for problem escalation. Users can also select this tab to find the storage machine type and serial number for an entitlement check.









Home

AutoSupport proactively monitors the health status of the storage system, and automatically sends the support data to the technical support site.


Storage

Hardware

Settings

Support





Note: AutoSupport is disabled by default setting.







Home

AutoSupport proactively monitors the health status of the storage system, and automatically sends the support data to the technical support site.


Storage

Hardware

Settings

Support





Note: AutoSupport is disabled by default setting.







Home

Storage

Hardware

Settings

Support



On the EVENT LOG page, users can see a record of changes and events that have happened on the storage array.









ThinkSystem SAN Manager overview

ThinkSystem SAN manager is a web browser-based GUI console for multiple DE Series systems. ThinkSystem SAN Manager can be installed on a Windows- or Linux-based host system. Users can also open TSM for each managed DE storage array through SAN manager. Following the 11.60.2 updates, users must use SAN Manager to set up synchronous or asynchronous mirroring.

Note: The synchronous and asynchronous mirroring features require the premium feature key installed through ThinkSystem System Manager.




Manage

Click the buttons on the left to see more information about the SAN Manager functions.

Operations

Certificate Management

Access Management





Manage

Operations


Certificate Management

Access Management

Support



Use the Manage page to discover storage arrays in the network, launch TSM for an array, import settings from one array to multiple arrays, and manage array groups. Select the check boxes next to the array names to perform operations on them, such as importing settings and creating array groups.






Manage

Use the Operations page to view the progress of batch operations, such as importing settings from one array to another.

Operations

Certificate Management

Access Management







Manage


The Certificate Management page manages certificates to authenticate between browsers and clients.

Operations

Certificate Management

Access Management







Manage


The Access Management page manages the user authentication for the SAN Manager interface.

Operations

Certificate Management

Access Management







Manage

Operations

Certificate Management

Access Management

Support



Lenovo

The Support page shows the technical support options, resources, and contacts.

SUPPORT

Access support and training resources to help you manage your storage array

Lenovo Product Support 2

Lenovo Data Center Support

Safety information, warranties and licenses, product documentation &

Related DE Series publications and links by Machine Type.

Warranty information 3

Search your entitlements for type, duration and status.

Support telephone list 2

Provides access to worldwide support phone list.

Safety information, licenses, and product documentation 3

Contains product overviews and full product technical information.

Lenovo Community 3

Navigate the Lenovo Community to ask questions and get feedback from other users about all DE series products.

Related Software Downloads 2

Find downloads for related software products.

Storage Manager overview

For the 11.50.x version, Lenovo Storage Manager is a host-installed GUI-based application required to support the System Manager Secure CLI interface (SMcIi), multi-path drivers, and multi-system firmware upgrades. Storage Manager supports both Windows or Linux host environments.

Storage Manager is needed along with SAN Manager to fully manage multiple storage arrays. Some of the Storage Manager functions – for example, firmware upgrade – are not integrated into the SAN Manager.

After the 11.6.2 release, Storage Manager only supports the following functions:

- SMAgent: Storage Manager Agent Package
 - SMAgent contains the software that provides a connection from the host's Ethernet port through the Fibre Channel I/O path to one or more Storage arrays.
- SMUtil: Storage Manager Utilities Package
 - o SMUtil contains utilities used to locate and register newly added volumes with the host's operating system.
- Smruntime: Storage Manager Runtime Package
 - Smruntime contains the core runtime environment shared by other Storage Manager packages



ThinkSystem DE plugin for vCenter overview

The DE plugin for vCenter provides integrated management of DE Series storage arrays with a vSphere Client. Most of the options in the DE plugin for vCenter GUI are similar to those in the ThinkSystem SAN manager.

The plugin requires VMware vCenter Server Appliance to be deployed in the VMware environment and an application host to install and run the plugin web server.

To install the DE plugin for vCenter, be sure that systems meet the following requirements:


- VMware vCenter Server Appliance supported versions: 6.7u3 or 7.0u1
- Controller firmware for Lenovo storage arrays: 11.60.2 or later
- Supported application host versions: Windows 2016 or Windows 2019
- Supported host protocols: iSCSI or FC

For more information about the DE plugin for vCenter, refer to the following documentation:

- ThinkSystem DE Plugin for vCenter: Installation and Configuration guide on <u>Lenovo Support</u>
- ThinkSystem DE Plugin online help on <u>ThinkSystem Storage Documentation</u>



ThinkSystem DE plugin for vCenter communications




When the DE plugin for vCenter has been installed, users can open vSphere Client and go to **Menu** → **Lenovo ThinkSystem DE Series Plugin** to manage DE Series storage arrays. Click the buttons on the left to see more information about the DE plugin for vCenter functions.

Manage

Certificate Management

Operations





Manage


Certificate Management

Operations

Support



Use the **Manage** page to discover storage arrays in the network, launch TSM for an array, import settings from one array to multiple arrays, and manage array groups. Select the check boxes next to array names to perform operations on them, such as importing settings and creating array groups.






Use the **Certificate Management** page to manage certificates to authenticate between browsers and clients.



Certificate Management


Operations








Use the **Operations** page to monitor the progress of batch operations. This includes importing settings from one array to another.










The **Support** page shows the technical support options, resources, and contacts.

Manage

Certificate Management

Operations







XClarity Administrator

Users can access XClarity Administrator (LXCA) to manage DE Series storage and other ThinkSystem server products at the same time. Users can also use the Inventory page to monitor DE storage status.

The following DE storage features are not supported in LXCA:

- Centralized user management
- Server certificates and Encapsulation
- Configuration Patterns
- Operating-system deployment
- Firmware and software updates
- Remote control
- Graphical view of hardware



Reference

For the latest DE series software documentations, go to Lenovo Storage Documentation website: https://datacentersupport.lenovo.com/tw/en/storagepubs/

